


Drawing	Accessories		
Refer ence	Qty	Item number	Description
1	1	63019001C	Tap n go head d 2
2	2	3960040R	Screws
3	1	4174278	Plate
4	4	3802004CR	Screw
5	1	4174283A	Skirt w/blade
6	1	4174275R	Blade
7	1	61042036	Guard assy
8	1	4199005A	Bushing
9	1	4199008B	Collar screw
10	1	4199004	Spring
11	1	4199014A	Nylon spool d.2.4
12	1	4095673R	3t blade
13	1	4199026B	Cover
14	1	61052031	Tool kit
15	1	62042015	Labels kit

### Walbro mod. WT-870

compl. p.n. 2318735R




15 ■ KIT RIPARAZIONE  
REPAIR KIT

16 ● KIT MEMBRANE & GUARNIZIONI  
DIAPHRAGM & GASKET SET




Drawing            Carburetor WT-870

---



Refer ence	Qty	Item number	Description
1	1	50010141	Screw
2	2	095000164	Circlip
3	1	072700211	Shutter
4	1	2318211	Pin
5	1	2318737	Shaft
6	1	072700347	Spring
7	1	2318837	Screw "I"
8	2	2318687	Cap
9	1	2318631	Screw
10	1	2318191	Cover
11	4	035000162	Screw
12	1	003300202	Screw
13	1	375100087	Cover
14	1	074000240	Adjust.screw
15	1	094600209	Repair kit
16	1	094600210	Diaph.+gasket
17	1	094600148	Spring



Drawing	Engine		
Refer ence	Qty	Item number	Description
1	1	50060012	Air purge
2	1	61200078R	Cylinder cover
3	2	4191069B	Plate
4	2	3801065R	Screw
5	2	3819036R	Washer
6	1	3916006	Washer
7	1	61200061R	Muffler
8	1	61200063R	Deflector
9	1	3055101	Spark plug
10	1	61200007AR	Muffler gasket
11	2	004000015R	Piston ring d.40
12	2	004900061R	Ring
13	1	50110047R	Piston pin
14	1	50120034	Piston assy
15	1	61202022	Cylinder assembly
16	1	50110044	Needle roller bea
17	2	50110043R	Spacer
18	1	61200001R	Crankshaft
19	1	61200064R	Stopper
20	1	61200113R	Crankcase
21	1	3860096	Screw
22	2	094000006	Bearing
23	1	61200006R	Gasket
24	2	094000099R	Seal ring
25	4	094000101R	Screw
26	4	3833073	Washer
27	2	3023008R	Plug
28	1	3916005	Washer
29	1	3819006	Washer
30	1	3801010R	Screw
31	2	3960030	Screw
32	1	3960032R	Screw
33	1	61202038R	Gasket set




Drawing	Frame		
Reference	Qty	Item number	Description
1	1	62022030	Buckle set
2	1	61250173R	Compl. harness
3	1	62040021R	Frame
4	1	3910024	Screw
5	1	61250131R	Support
6	4	3819006	Washer
7	4	3801013	Screw
8	1	62040023R	Support
9	1	62030020	Spacer
10	4	58040079AR	Spring
11	1	62030067	Hub
12	8	3801011	Screw
13	4	3918005	Washer
14	1	3914014	Nut
15	4	3918006	Washer
16	4	3914003	Nut
17	1	3916010	Washer



Drawing Fuel tank and air filter

---


Refer ence	Qty	Item number	Description
1	1	61200019AR	Gasket
2	1	61200198	Insulator
3	2	3801015	Screw
4	1	61202025R	Support
5	1	61200196R	Gasket
6	1	2318765R	Carburetor WT-869
7	1	61200025AR	Air filter
8	1	61200075R	Cover orange
9	1	62042010R	Tank
10	1	4098377	Clip
11	1	61200092AR	Tube
12	1	61200093R	Tube
13	1	4161211	Bush
14	1	61070011A	Tank breather
15	1	61200030AR	Tube
16	1	61070079R	Compl. cap
17	1	61070006	Gasket
18	1	50010218R	Fuel filter
19	4	3801016	Screw
20	4	3918005	Washer
21	5	3801013	Screw
22	4	3819006	Washer
23	2	61052009B	Screw
24	1	61200024R	Lever
25	1	3960069AR	Screw
26	1	61200023R	Lever
27	1	4120070	Washer
28	4	61250143R	Spacer
29	4	3916008R	Washer
30	4	61200129R	Spring




Drawing Starter assy and clutch

---

Refer ence	Qty	Item number	Description
1	1	61200074AR	Starter assy
2	1	61200015R	Handle
3	1	56520087R	Starter rope
4	8	3801010R	Screw
5	4	3916005	Washer
6	1	004000132R	Spring
7	1	56520038AR	Pulley
8	1	3027005R	Snap ring
8	4	3801010R	Screw
9	1	56520039A	Insert
10	1	56520040A	Plate
11	1	3918020	Washer
12	1	61200012R	Spark plug cap
13	1	61200062AR	Clutch driver
14	1	61250015AR	Ignition coil
15	1	61200042R	Cable
16	2	3801013	Screw
17	2	3819006	Washer
18	1	3912009	Nut
19	1	3818011A	Washer
20	1	61250014AR	Flywheel
21	1	4197011	Pin
22	1	4191153AR	Clutch
23	1	4191028R	Spring
24	1	4191027ER	Pin
25	1	4193005R	Clutch drum
26	1	3035019R	Bearing
27	1	3024015	Seeger ring
28	1	62040029R	Starter case
29	1	3025022	Seeger ring
30	1	61200067R	Spring



Drawing	Transmission		
Refer ence	Qty	Item number	Description
1	1	4197056	Guard assy d.26
2	1	61040050A	Lever
3	1	61040051	Switch
4	1	61040057	Spring
5	1	61040052	Pawl
6	1	61040049	Throttle lever
7	1	61040056	Spring
8	1	61010019	Band d.26
9	1	61040053	Plate
10	1	61040054	Plate
11	1	3960061AR	Screw
12	3	3960067AR	Screw
13	1	3801011	Screw
14	1	3914003	Nut
15	1	61012006A	Handle
16	1	61250216R	Cable
17	1	62040025R	Throttle cable
18	4	3801017R	Screw
19	6	3819006	Washer
20	4	3918010	Washer
21	1	61010024R	Clamp
22	1	61032012	Compl. handle 26
23	2	3801015	Screw
24	1	61042026	Step guard assy
25	1	62020012	Eyelet
26	1	4197074	Tube d.26
27	1	4197019R	Shaft d.26
28	1	4197077	Extension d.26
29	1	4193078	Spring
30	1	4197004	Joint 26
31	1	3022010	Pin
32	1	3049009	O-ring
33	1	4197062	Guard
34	1	4137005DR	Flexible shaft
35	2	3049008	O-ring
36	1	4197018ER	Flexible assy
37	1	61040132	Bevel gear d.26
38	1	3901016	Screw
39	1	4100456R	Guard
40	1	3901008	Screw
41	1	4138311A	Washer
42	1	61040071R	Cap
43	1	61050013R	Gear case d.26
44	1	3034008	Bearing
45	1	61040106A	Pin
46	1	3050018R	Sealing ring
47	1	61040074AR	Screw
48	1	4179089R	Flange
49	1	3025022	Seeger ring



Drawing	Transmission		
Reference	Qty	Item number	Description
50	1	3034012R	Bearing
51	1	61052030BR	Bevel gear d.26
52	1	3025009	Seeger ring
53	1	3035230	Bearing
54	1	3024010R	Snap ring
55	1	61040066	Spacer
56	1	3034218	Bearing
57	1	61040145R	Hub
58	1	3025018	Seeger ring
59	1	4197072	Grip-end d.26
60	1	62010010A	Throttle cable
61	1	044000058A	Cable joint
62	1	4197017ER	Sheath l.916