


## Drawing      Accessories

---

Reference	Qty	Item number	Description
1	1	4199039R	Compl. nylon head
2	2	3960040R	Screws
3	1	4174278	Plate
4	4	3802004BR	Screws
5	1	4174283A	Skirt w/blade
6	1	4174275R	Blade
7	1	61042011A	Guard assy
8	1	4199005A	Bushing
9	1	4199008B	Collar screw
10	1	4199004	Spring
11	1	4199042R	Nylon spool
12	1	4199035R	Cover
13	1	4095663R	Blader disk
14	1	61052031	Tool kit
15	1	61200106R	Harness
16	1	61202016	Labels kit

**Zama mod.C1Q-E12**  
 compl. p.n. 2320051R



- 16 ● KIT MENBRANE & GUARNIZIONI  
 DIAPHRAGM & GASKET SET
- 15 ■ KIT RIPARAZIONE  
 REPAIR KIT


Drawing      Carburettor C1Q-E12 (till 30/09/07)

---

Reference	Qty	Item number	Description
1	1	2318388	Screw
2	1	2318387	Ring
3	1	2318872	Shutter
4	1	2318412	Hooking spring
5	1	2318689	Shaft
6	1	2318528	Spring
7	1	2318696	Screw H
8	2	2318687	Cap
9	1	2318697	Screw L
10	1	2318880	Cover
11	2	2318522	Screw
12	2	2320053	Screw
13	1	2320052	Cover
14	1	2318876	Screw
15	1	2318886	Repair kit
16	1	2318885	Diaphragm set
17	1	2318535	Ring

### Walbro mod. WT-869

compl. p.n. 2318765R




15 ■ KIT RIPARAZIONE  
REPAIR KIT

16 ● KIT MEMBRANE & GUARNIZIONI  
DIAPHRAGM & GASKET SET

Drawing      Carburettor WT-869 (from 01/10/07)

---

Reference	Qty	Item number	Description
1	1	50010141	Screw
2	2	095000164	Circlip
3	1	072700211	Shutter
4	1	2318211	Pin
5	1	2318737	Shaft
6	1	072700347	Spring
7	1	2318837	Screw "I"
8	2	2318687	Cap
9	1	2318631	Screw
10	1	2318191	Cover
11	4	035000162	Screw
12	1	003300202	Screw
13	1	375100087	Cover
14	1	074000240	Adjust.screw
15	1	094600209	Repair kit
16	1	094600210	Diaph.+gasket
17	1	094600148	Spring





# Drawing      Engine

---

Reference	Qty	Item number	Description
1	1	50060012	Air purge
2	1	61200078R	Cylinder cover
3	2	4191069B	Plate
4	2	3801069	Screw
5	2	3819010	Washer
6	1	3916006	Washer
7	1	61200018R	Muffler
8	1	61200063R	Deflector
9	1	3055115	Spark plug
10	1	61200007AR	Muffler gasket
11	2	004000015R	Piston ring d.40
12	2	004900061R	Ring
13	1	50110047R	Piston pin
14	1	50120034	Piston assy
15	1	61202022	Cylinder assembly
16	1	50110044	Needle roller bea
17	2	50110043R	Spacer
18	1	61200001R	Crankshaft
19	1	61200064R	Stopper
20	1	61200113R	Crankcase
21	1	3860096	Screw
22	2	094000006	Bearing
23	1	61200006R	Gasket
24	2	094000099R	Seal ring
25	4	094000101R	Screw
26	4	3833073	Washer
27	2	3023008R	Plug
28	1	3916005	Washer
29	1	3819006	Washer
30	1	3801010R	Screw
31	2	3960030	Screw
32	1	3960069R	Screw

Drawing Fuel tank and air filter




## Drawing Fuel tank and air filter

---


Reference	Qty	Item number	Description
1	1	61200019R	Gasket
2	1	61200020R	Insulator
3	2	3801015	Screw
4	1	61202025R	Support
5	1	61200021R	Gasket
6	1	2318765R	Carburetor WT-869
7	1	61200025R	Air filter
8	1	61200075R	Cover orange
9	1	61200028AR	Complete tank
10	1	4098377	Clip
11	1	61200092R	Hose
12	1	61200093R	Tube
13	1	4161211	Bush
14	1	61070011A	Tank breather
15	1	61200030AR	Tube
16	1	61070079R	Compl. cap
17	1	61070006	Gasket
18	1	094600450R	Fuel filter
19	1	61200057R	Stand
20	5	3819006	Washer
21	5	3918005	Washer
22	1	3801013	Screw
23	2	61052009B	Screw
24	1	61200024R	Lever
25	1	3960069R	Screw
26	1	61200023R	Lever
27	1	4120070	Washer
28	4	61200128R	Spacer
29	4	3916008R	Washer
30	1	61200129R	Spring
31	4	3801016	Screw

Drawing Starter assy and clutch



Fino a  
Till  
Jusqu'a  
Hasta  
Bis





23/01/07  
matr. 2047046943



## Drawing Starter assy and clutch

---

Reference	Qty	Item number	Description
1	1	61200074R	Starter assy
2	1	61200015R	Handle
3	1	56520087R	Starter rope
4	6	3801010R	Screw
5	4	3916005	Washer
6	1	004000132R	Spring
7	1	56520038AR	Pulley
8	1	3027005R	Snap ring
9	1	56520039A	Insert
10	1	56520040A	Plate
11	1	3918020	Washer
12	1	61200012R	Spark plug cap
13	1	61200062AR	Clutch driver
14	1	61200010R	Ignition coil
15	1	61200042R	Cable
16	2	3801013	Screw
17	2	3819006	Washer
18	1	3912009	Nut
19	2	3818011A	Washer
20	1	61200009AR	Flywheel
21	1	61200059R	Adaptor
22	2	3801015	Screw
23	1	61200060R	Adaptor
24	2	3914003	Nut
25	1	4161364	Bushing
26	1	4161428	Sleeve
27	1	3024015	Seeger ring
28	1	61200071AR	Starter case
29	1	3035019R	Bearing
30	1	3025022	Seeger ring
31	1	61200032R	Clutch drum
32	1	4191027ER	Pin
33	1	4191028R	Spring
34	1	4191153AR	Clutch
35	1	61200067R	Spring
36	1	61250015AR	Ignition coil
37	1	61250047R	Cable
38	1	61250014AR	Flywheel







# Drawing      Transmission

---

Reference	Qty	Item number	Description
1	1	61040106A	Pin
2	2	3801015	Screw
3	2	61170132	Grommet
4	1	4160262B	Knob
5	5	3801013	Screw
6	1	61040145R	Hub
7	1	074000183R	Clamp
8	1	3960021	Screw
9	1	4100456R	Guard
10	1	61202023R	Tube Ø26
11	8	3914003	Nut
12	1	2317021R	Switch
13	1	4138358R	Button
14	1	4138360R	Spring
15	1	4174246R	Lever
16	1	4174245BR	Throttle lever
17	1	4138361R	Spring
18	1	61040066	Spacer
19	1	4100098BR	Spring
20	2	3960029	Screw
21	1	3801016	Screw
22	1	61040140R	Knob
23	1	61200049R	Handlebar
24	1	61040131R	Handle
25	1	61200047R	Throttle cable
26	1	61200046R	Cable
27	1	61200048R	Handlebar
28	1	61170075R	Drive shaft
29	2	072700082R	Shock absorber
30	1	3901008	Screw
31	1	4138359R	Button
32	1	61052030BR	Bevel gear d.26
33	1	3024012	Ring
34	1	3035230	Bearing
35	1	4161619R	Compl. band
36	1	3025019	Ring
37	1	4179089R	Flange
38	1	3034008	Bearing
39	1	4138311A	Washer
40	1	3025009	Seeger ring
41	1	61040132	Bevel gear d.26
42	1	61040071R	Cap
43	1	61050013R	Gear case d.26
44	1	3034218	Bearing
45	1	61040074AR	Screw
46	1	3034012R	Bearing

---



Drawing      Transmission

---

Reference	Qty	Item number	Description
47	1	3025022	Seeger ring
48	1	3050018R	Sealing ring